Motorola Atrix 4G Battery Replacement

This guide will attempt to help individuals in successfully replacing the battery in a Motorola Atrix 4G phone.

Written By: Derek Walker



INTRODUCTION

This guide will show you how to remove the battery from the Motorola Atrix 4G.

TOOLS:

- Spudger (1)

Step 1 — Battery



- Pry the rear cover from the back of the phone.

Step 2





- Insert a spudger or plastic opening tool into the small notch at the base of the battery.
- Lift the battery out of the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 12:32:29 PM.